## Installation Manual







#### Installation Warnings

- To avoid the risk of fire, explosion, or electric shock, this product should be installed, inspected, and maintained by a qualified electrician only, in accordance with the National Electrical Rules and all other local codes.
- Ensure the supply voltage is the same as the rated voltage of the Bay Light.
- · Be certain electrical power is OFF before and during installation and maintenance.
- Proper grounding is required.
- Use care in handling unit to avoid impact and scratching of the glass surface.
- Do not allow foreign substances to accumulate on the glass.
- Do not handle or move by grasping any electrical cable, as this may compromise the internal connections.
- The determination as to the suitability of this product is the responsibility of the end user.
- Using the product in a manner not recommended will void the warranty and may result in a dangerous condition, a degradation of performance, or a shortened lifespan of the fitting.
- This unit should be used for down lighting ONLY.
- Use only in conditions where electrical supply is stable.
- Do not disassemble or make any modifications to the unit unnecessarily.
- · Always install using safety wire included.
- The unit may produce enough heat to support combustion if flammable objects are allowed to come in contact. Do not cover the light or deflect the beam with paper cloth or any other flammable material.

#### Notice before handling

- Do not arbitrarily assembly and disassemble.
- Installation and repairs must only be carried out by licensed electrical contractors and engineers because of safety risks.

#### **Basic Accessories**

Safety wire's length: 700mm(safety load: < 40Kg)</li>









# Installation Manual

### Installation

